

Fitting Instructions #4670IS

Alfa Romeo 156 Crosswagen

Differential Mount Bushing (Rear)

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Jack the vehicle up and support on jack stands/hoist;
- Use a separate jack to support the rear differential and then, remove the bracket on the differential;
- Remove original bushings including the steel shell from the housing with the use of a hydraulic press and suitable pressing tools;
- Apply the grease supplied to all mating surfaces;
- Push the new polyurethane bushing into the housing as shown in the diagram, and then the crush tube;
- Refit the bracket onto the rear differential and tighten all bolts to manufacture's torque settings;
- Road test the vehicle and do a safety check after 1000km.

