

# Fitting Instructions #2875IS

Mazda MX5 NA and NB

## Differential Mount Bushing



- Jack vehicle up and put on stands/hoist;
- Carefully support differential and remove all the bolts and washers of the differential housing mounts;
- Lower differential low enough to slot bushing in;
- Grease up the surface of the inserts in contact with the OE bushes and insert them into the voids with reference to the diagram, locate 2875A to the upper and 2875B to the lower side of the differential bushes;
- Refit and tighten all washers and bolts to the vehicle. Ensure that you use manufacturers torque settings.

