

Fitting Instructions #0787IS

Mitsubishi Magna

Control Arm Lower Rear Bushing



Special note: polyurethane bushes be fitted to both sides.

SPF0426K - Standard Alignment

Contains:

- 2 X SPF426 Bushes, original equipment style bushes which will maintain existing caster settings.

SPF0651K - 0.5 Degree Caster Adjustment Left Side

Contains:

- 1 x SPF426 Bush to be fitted to the right hand side (Maintains existing caster setting);
- 1 x SPF651 Bush to be fitted to the left hand side (Off-set hole gives +0.5 degree caster).

SPF0787K - 0.5 Degree Caster Adjustment Per Side

Contains:

- 2 x SPF651 Bush (+0.5 degree caster left-side / -0.5 degree caster right-side).

Note: mounting brackets and pivot shafts must be free of dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with the grease provided.

- Fitting the appropriate bush to the car. The word "front" is moulded to the bush. This is to face downwards & to the front of the car (the word "front" is visible once fitted);
- All mounting bolts are to be torqued to manufacturers specifications with the vehicle at-ride height.