

Fitting Instructions #0949IS

Hyundai S Coupe / Excel / Pony

Control Arm Lower Rear Bushing

Special Note: polyurethane bushes must be fitted to both sides.

Kit #0949K - Standard Alignment

Contains:

- 2 x 0949 bushes, original equipment style bushes which will maintain existing caster settings.

Kit #0950K - 0.6 Degree Caster Adjustment Left Side

Contains:

- 1 x 0949 bush. To be fitted to the right hand side (maintains existing caster setting);
- 1 x 0951 bush. To be fitted to the left hand side (offset hole gives +0.6 degree caster).

Kit #0951K - 0.6 Degree Caster Adjustment Left Side

Contains:

- 2 x 0951 bush. (0.6 degree caster left-side / -0.6 degree caster right-side).

Note: Mounting brackets and pivot shafts must be free of dirt, rust and corrosion. Ensure that all the bush surfaces in contact with metal are coated with the grease provided. All mounting bolts are to be tightened to the torque of the manufacturer's specifications with the vehicle at ride height.