

Fitting Instructions #4429IS

Hyundai Getz

Rear Beam Axle to Chassis Bushing

Superpro
Suspension Parts

- With the vehicle on jack stands/hoist, undo the bolts and lower the beam axle;
- With suitable tool, press the factory shell bushes out;
- Clean housing areas to remove any old original bushing materials;
- Apply the grease supplied to outside and inside surfaces of the bushes and the outside of the steel crush tubes;
- Install the new bushes according to the orientation shown in figure, placing the plastic washer on the outer position;
- Refit the beam axle to the original position and tighten the bolts;
- Ensure that all fasteners are torque to manufacturer's specification and carry out a wheel alignment.

