

Fitting Instructions #4793IS

Mercedes S-Class

Front Sway Bar Link to Chassis Bushing

Note: This kit must be fitted to both sides of the vehicle.

- Wheel align the vehicle before the job is started and note wheel alignment settings;
- Remove the front sway bar links;
- Remove the OE bushes and clean sway bar end (peg) and the link housing;
- Install the new sway bar link bushes, as shown in the illustration, and repeat the procedure to the other link;
- Reinstall the sway bar links on the vehicle;
- Tighten the bolts and ensure that they are torque to manufacturer's specification;
- Wheel align vehicle and check new settings.

