

# Fitting Instructions #1374IS

Nissan Pulsar / Sentra / Sunny / Almera / EXA

## Control Arm Lower Rear Bushing



- Before removing the front lower control arm rear bushes from the vehicle; wheel alignment settings need to be taken;
- Remove the front lower control arm rear bushes from the vehicle. The bushes can be removed from the pin by pulling and rotating them;
- Fit the washer onto the pivot pin. The steel washers supplied with this kit **MUST BE USED** to resist movement under braking. The washers supplied are an interference fit on the pivot pin and can be effectively fitted using a steel tube with the internal diameter of approximately 28mm and a ball pin hammer;
- The bushes can then be fitted. Ensure that the internal diameter of the bush and the external diameter of the pin are greased with the grease supplied;
- Refit the front lower control arm rear bushes to the vehicle and tension all the bolts to the manufacturer's specifications;
- After the bushes have been fitted, wheel align the vehicle.