

# Fitting Instructions #1324IS

Toyota Cressida

***Strut Bar to Chassis Mount Kit***

---



**Note:** This kit requires the original equipment steel washers to be re-used . The rubber bonded to the front washer must be removed by the following procedure.

**This procedure must be carried out in a well-ventilated area using the appropriate safety equipment.**

- Having removed the front washer from vehicle, use an Oxy-acetylene/propane torch to warm the washer, to destroy the rubber bond. (Excessive heat is not required; do not allow the rubber to catch fire. A little smoke may be produced when the steel is hot enough to release the bond.) Further heating can be used to clean any remaining rubber from washer. Use a wire brush to complete the job;
- Alternately, a wire buff may be used to remove all the rubber from the washer, taking care to ensure the wire buff does not snatch the washer from your grip. A suitable pair of pliers or vise grips may be used for this operation;
- Using grease supplied, Grease inside of chassis hole, grease outside of bushing and install in to the chassis. Grease new steel tube and install in bushings. The Strut bar can now bolted into place using the washers in their original positions.