

# Fitting Instructions #0121IS

Holden Gemini / Open Kadett

## Steering Coupling Bushing

- Rivet heads to be removed with 3/8 drill after marking with centre punch;
- Use a 5/6 punch to drive out rivets;
- Using hardware supplied and all original washers, re-assemble as shown.

**Note:** Safety collar must be retained.

