

Fitting Instructions #RS005IS

Holden Colorado RG, Isuzu D-Max TFR, TFS, RG01

Front Strut Cap (Suits vehicles from 01/12 – 03/13, with flat ground coil)

- Remove front strut from the vehicle.
 - Take note** of the top mount to shock lower mount orientation. Use one of the studs on the top mount as a reference.
- Use a spring compressor to compress the spring and then, remove the worn/original strut cap assembly.
- Install new SuperPro strut cap assembly as per the arrangement shown in the image below.
 - Note: **Re-use original top nut.** Use hand tools to tighten top nut and ensure the nut is tightened to manufacturers torque specifications.
- Refit the front strut to the vehicle.
- All mounting bolts are to be tightened to manufacturers specifications.

