

Fitting Instructions #1253IS

BMW 3 Series E36

Control Arm Lower Rear Bushing



- Raise vehicle and suspend on safety stands;
- Remove lower control arm;
- Mark bush housing in relationship to control arm and press bush of control arm pin;
- Press O.E. bush from housing. Clean inside housing of any loose material;
- Lightly grease O.D. of new bush and press into housing making sure the side with the recess faces towards the front of the vehicle and the bracket aligns with the original marks;
- Tap washer supplied onto lower control arm pin with shoulder facing towards the bush. Grease internal diameter of bush then push bush with bracket onto pin;
- Rebolt control arm to vehicle;
- Tighten all mounting bolts to the manufactures specs.