

# Fitting Instructions #3970IS

## Fiat Doblo Van (Second Generation)

### Shock Absorber Upper and Lower Bushing (Front)



**Note:** Polyurethane bushes must be fitted to both sides of the vehicle.

- With the vehicle on jack stands/hoist, remove rear wheels and then remove the rear shock absorbers from the vehicle;
- Remove the OE bushing by using a hydraulic press or other suitable tool to push them out;
- Ensure that the grease supplied is used on all contacting surfaces prior to the assembly of new polyurethane bushes;
- Position the bushes as shown in the figure above and then, use a hydraulic press to press the bushes into the housing/shock eye;
- Apply the grease supplied to the bore of the bushes and the outside of the steel crush tube. Then push the crush tube in;
- Refit the rear shock absorbers and rear wheels to the vehicle;
- Ensure all bolts are tightened to the manufacturer's specification and then proceed to have the vehicle wheel-aligned.

