

# Fitting Instructions #1884IS

Ford Cortina

## Steering Coupling Bushing



- Remove the steering coupling from the vehicle;
- Disassemble it, removing the OE bush, nuts, washers, bolts and bush;
- Assemble back together with new SuperPro parts as shown in the figure below;
- Re-install the steering coupling in the vehicle.

