

# NISSAN QQ AND GU PATROL

**Fitment for drivers side and passenger side trailing arms to increase caster. Bush and Tube fitment is identical for both arms.**

**Lay the trailing arm on this template and mark the bush positions as indicated.**

**Press in the bush with the hole closest to the mark. Distance between hole centers must be  $240\pm 1$ mm for easy fitting.**

**FRONT**

240

