

Fitting Instructions #3114IS

Mazda 3

Sway Bar Bushings

- Remove the original sway bar to chassis mount bracket and rubber bushing from the vehicle;
- Clean any remaining rubber or flaking material from the mounting area and or the sway bar;
- Install new inner bushing onto the sway bar making sure that the flats on the inner bushing locate on the flats on the original sway bar;
- Use the grease supplied and lubricate the inside of the new outer bushing and the outside of the new inner bushing;
- Install the outer bushing over the inner bushing as per the drawing below. Insuring that the cuts are diametrically opposite;
- Install the sway bar to chassis mount bracket and mounting bolts into the vehicle;
- Tighten all mounting bolts and nuts to the manufacturers specifications.

Note:

- It will not fit MPS;
- For Original S/Bar with 2 flats on the bar.

