

Fitting Instructions #RC0039RZIS

Nissan Pulsar

Sway Bar Stabiliser Kit

This work should be carried out by qualified persons.

- Raise vehicle and support on Jack stands;
- Fit the New Roll control Bracket supplied into the rear Beam mount just inside the disc rotor, (There are 2 existing holes) as per photo, leaving the Nuts loose at this stage;



- Fit the Sway bar to the brackets using 3 cap screws per side. Note the 2 mounting positions below;



- Tighten all bracket bolts first and then tighten the bar bolts. Torque all nuts and cap screws approximately 46Nm;

Note: A drop of Loctite is recommended on all bolts.



Please drive carefully to get used to the new handling characteristics.

Fulcrum Suspensions and Roll Control do not take responsibility for incorrect fitment or misuse of this product.

Pictures are indicative and are not necessarily exact to the B.O.M.