

Fitting Instructions #4844IS

Honda Jazz GK

Control Arm Lower front Kit



Note: Polyurethane bushes must be fitted to both sides of the vehicle.

- Jack the vehicle up and support on jack stands. Then, remove the lower control arms.
- Remove original parts from the housing with the use of a hydraulic press and suitable pressing tools.
- Note for the front bush: lubricate the body of the bushes and push them into the arm. Next, lubricate the bore of the new bushes and the outside of the steel crush tube. Then, use an arbour press to push the steel crush tube into the bushes.
- Refit the control arm to the vehicle. Tighten all bolts to manufactures torque settings.
- Carry out wheel alignment.