

Fitting Instructions #1213IS

Toyota Supra / Celica

Control Arm Inner Bushing



Note: The original outer shells are to remain in the control arms and must not be removed.

This procedure needs to be carried out in a well-ventilated area.

- Use an oxy - acetylene torch to warm the outer Control Arm to destroy the rubber bond between the shell and rubber;
- Ensure that all remaining rubber is removed and the housing is cleaned;
- The Polyurethane bushes are marked on the Flange Heads "Inner" & "Outer";
- The bushes marked "Inner" must be placed on the inner side of the Wishbone Control arm;
- The bushes marked "Outer" must be fitted on the outer side of the Wishbone Control arm;
- Use the Grease supplied to grease all components and assemble.