

Fitting Instructions #0351IS

Ford Cortina TE, TF

Steering Rack & Pinion Coupling Kit



- Rivet heads to be removed with 3/8 drill after marking with centre punch;
- Use 5/16 pin punch to drive out rivets;
- Using hardware supplied, re-assemble as shown.

Note: safety collar must be retained.

