

Fitting Instructions #1546IS

Ford Fiesta Mk1, Mk2 and Mk3

Trailing Arm Bushing Kit

- Remove trailing arm from vehicle;
- Press the original shells out of the control arm without distorting the control arm;
- Press the new shells supplied in the kit into the control arm. The shells are pressed into the control arm from the side as shown:



- The shells are to be pushed into the control arm before the polyurethane bush is pressed in the shell. Push the shells into the control arm until the step on the shell touches the control arm;
- After the shells have been pushed into the control arm, the bushes can be pushed into the shell. Ensure that the outside diameter of the bush and the inside diameter of the shell is greased before the bushes are pressed in;
- Once the bushes have been pushed into the shells the crush tube can be pushed into the bush. Again, ensure that the bore of the bush is greased before fitting the crush tube;
- Refit the control arm into the vehicle. Tension all the bolts to the manufacturer's specifications.