

NISSAN NAVARA D22 UTE & CAB CHASSIS 02/97 – 06/15

PART NO.

UNT230

1. Locate the 8 way tail light connector on rear passenger side chassis.
2. Disconnect this 8 way connector.
3. On the Wiring Harness connect the corresponding 8 way connectors.
4. Earth the white earth terminal directly to chassis.
5. Using cable ties, secure the cable along desired route and the required length.
6. Fit the required socket to the wiring harness and mount the plug to desired position.
7. Test towbar wiring with a trailer testing box.

