

FITTING INSTRUCTIONS

PART NUMBER: **T2P566**



VW Amarok Style Side with Step 02/11 on Towing Capacity 2800Kg / Ball Load 280Kg Lug # L4045

- 1) Fit tow bar to rear step with 4 x M12 bolts and washers.
- 2) Tighten all bolts to torque settings.
- 3) Fit ball mount with pin and clip supplied.
- 4) Fit door sticker supplied to door.
- 5) Re fit exhaust rubbers and mud guard.

ECU MUST BE FITTED WITH THIS TOW BAR
ECU SOLD SEPARATELY

RECOMMENDED ASSEMBLY

TORQUE LISTING

| <u>Diameter</u> | <u>Grade 8.8 Bolt</u> |
|-----------------|-----------------------|
| | Nm |
| M6 | 9.5 |
| M8 | 21.7 |
| M10 | 43.4 |
| M12 | 77.3 |
| M16 | 189.8 |