

Instructions

Front Swaybar - Quick Release Links

This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - Jeep Wrangler
- JK Series

Contents

- 2x complete links
- ball joint and bushing.
- 2x 12mm ID washers for ball joint
- 2x M12 nyloc nuts for ball joints
- 2x diff brackets
- 2x 1/2 inch bolts for diff bracket
- 2x 1/2 nyloc nuts for diff bracket
- 2x 1/2 inch flat washers
- 2x chassis brackets
- 4x small flange bolts - for chassis
- 2x R clips
- 2x large R clip washers
- 2x disconnect studs
- 2x M12 flange nuts for disconnect studs
- 2x M12 flat washers for disconnect studs
- 2x chassis studs
- 2x 3/8 nyloc nuts for chassis studs



- Raise vehicle evenly and safely support.

Never rely on a Jack only

- Remove original links from vehicle.
- Proceed to bolt up diff brackets to diff using 1/2 nut/bolt and flat washer

Note - depending on your model, the diff bracket may be bolted on either side of diff.

- Bolt up disconnect pin using M12 flange nut and washer

Note - place washer between bracket and link bushing (not under flange nut)



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Front Swaybar - Quick Release Links

This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.



- Bolt up link to swaybar with nyloc nut and M12 washer - place washer between swaybar ball joint (not under nut)

Note - check turn buckle is evenly screwed into both ends.

- This product is designed for raised vehicles 2-6 inches.

****For best performance, confirm swaybar is near horizontal (parallel with the road) when vehicle is at ride height****

Adjust turn buckles to remove any pre-load from LH side verse RH side
Then tighten lock nuts

Large flat washer and R clip



- Bolt chassis pin up to chassis bracket using 3/8 nut flat washer.

Remove swaybar link from diff pin and place over chassis pin.

Align bracket on chassis and centre punch the chassis - now drill 2x holes with 6.5mm drill bit.

- Bolt up bracket with 2x small flange nuts

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.