

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Contents -

- 1x 20mm swaybar
- 2x mount bushings
- 2x mount brackets
- 2x bump-stops
- 2x link brackets
- 2x U-bolts (with nuts/s/washers)
- 4x M10 bolts
- 4x M10 nuts
- 4x large flat washers
- 4x small flat washers
- Grease

Application - Toyota Hilux 4WD 2005-2015

(Refer current catalogue listing)

- Raise rear of vehicle evenly - under Differential.
- Loosen Leaf U-bolts - enough to remove OE bump stop.



- Grease mount bushing and pop over swaybar.
- Push supplied bump-stop into supplied mount bracket.
- Feed swaybar in via LH side
Note - hump for brake line.
- Assemble bracket/mount as per image.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Rear Swaybar Kit

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Continued -

- Pop U-bolts over chassis rail
Careful of wiring on LH side.
- Grease link bushing face's.
- Assemble link bracket.
- Loosely bolt up link with supplied M10 hardware - place large flat washers on link side.
- Place link in centre hole of swaybar blade initially.



- Confirm swaybar and links are central at ride height.
- Proceed to tighten all nuts and bolts.
- It is important to re-check all hardware after initial 100kms travelled.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.