

Install Guide

Front Upper A-Arms - Fixed Geometry Improvement

Note: These components must be fitted by a qualified person only, as per the manufacturers service manual. Also, that all relevant safety procedures are followed in addition to below.

Application - Dodge Ram 1500
- DT 2019-on

Install Guide

(Always refer current catalogue listing)

- Raise vehicle evenly and safely support with a hoist or stands.

Contents - 2x fixed, forged tubular arms
- complete with H/D ball joints

Never rely on a Jack only

- Start by removing the front wheels.
- Loosen and remove the inner bushing bolts.

Remove from original arm from vehicle.



- Remove split pin from ball joint nut - then loosen. Don't remove nut just yet.
- Strike aluminium hub (up-right) to break ball joint taper. only.

Moderate force only should be needed.

Refer Page 2 -

Install Guide

Front Upper A-Arms - Fixed Geometry Improvement

Note: These components must be fitted by a qualified person only, as per the manufacturers service manual. Also, that all relevant safety procedures are followed in addition to below.

- Proceed to bolt up new supplied arms

Note - both arms look similar.

Be sure to check for LH and RH stickers on each arm.


- Bolt up new arm to inner clevis with original bolts.

Refer RH image.



- Bolt up ball joint to hub using new supplied castle nut.
- Be sure to fit new split pin (safety pin).

Refer LH image.



Refer page 3

Install Guide

Front Upper A-Arms - Fixed Geometry Improvement


Note: These components must be fitted by a qualified person only, as per the manufacturers service manual. Also, that all relevant safety procedures are followed in addition to below.

- The installation is now complete.

IMPORTANT - a wheel alignment will be required immediately after install.

- Road test vehicle.

Refer RH image



- Re-check all bolts after 1000kms