

# Instructions

## Handbrake Cable

### - Extension Spacers

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

**Application** - Holden Colorado  
 - Isuzu D-Max  
 - 2012-on

Note - this kit is suited for raised trucks only.

*Always refer complete catalogue listing*

**Contents** - M8 x 40mm bolt x2  
 - Spring washer x2  
 - Flat washer x2  
 - Steel spacers 25mm long x2

- Raise vehicle evenly and safely support.

*Never rely on a Jack only.*

- Un-bolt original bolt from leaf spring (both sides)
- Refer image below for assembly.
- Tighten to 25Nm

Supplied spacer

Place supplied washers  
 under bolt head.



**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.