

# Instructions

## Extension Brackets

### - Swaybar and Head-light Sensor

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

*Page 1 of 2*

**Note - this kit can be installed at ride height or while lifted.**

**Application** - Nissan Navara  
- NP300

*Always refer complete catalogue listing*

**Contents** - 2x Link brackets  
- 1x Head-light sensor bracket  
- 2x M12 x 35mm bolt  
- 1x M8 x 25mm bolt  
- 2x Flat washers  
- 2x Spring washers



- Un-bolt upper swaybar link nut.

- Using supplied brackets, M12 bolts and washers - bolt up bracket as per image.

- Place washers and nut on the inside.

- Bolt up original swaybar link to lower hole as per image.

**RH side bracket shown**



**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

# Instructions

## Extension Brackets

### - Swaybar and Head-light Sensor

Page 2 of 2

Continued;

**Application** - Nissan Navara  
- NP300

*Always refer complete catalogue listing*

**Contents** - 2x Link brackets  
- 1x Head-light sensor bracket  
- 2x M12 x 35mm bolt  
- 1x M8 x 25mm bolt  
- 2x Flat washers  
- 2x Spring washers

- Un-bolt original head-light bracket.

Discard bracket but retain original bolt.

Note - supplied bracket has 2 holes.  
- upper hole suited for 2 inch lifted.  
- lower hole suited for OE height.



- Bolt up new supplied bracket as per image.

Use supplied M8 bolt.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.