

# Instructions

## ABS Wiring - Extension Kit

**N.B:** This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

**Application** - Mitsubishi Triton  
- MQ Series

*Always refer complete catalogue listing*

**Contents** - M8 x 40mm bolt x1  
- M8 spring washer x1  
- M8 flat washer x1  
- Spacer 20mm long x1



- Raise rear of vehicle evenly and safely support

*Never rely on a Jack only.*

- Locate ABS bracket bolt on top of differential - refer image 1.

- Remove original bolt and discard.

- Add supplied spacer, along with supplied flat and spring washer.

Tighten to 20Nm.



20mm spacer

**N.B:** It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.