

Installation Guide

HEA VY DUTY FRONT SWAYBAR

Z 5351

Suits: Nissan Patrol

(Always refer to the current catalogue for complete application listings)

N.B: These instructions should be used in conjunction with the workshop manual.

1. Raise vehicle evenly and safely support.
2. Unbolt swaybar saddles and remove OE swyabar.
3. Confirm which D bushings (supplied) bests suits your OE saddles.
Discard the other 2 as these will not be required.
4. Bolt the new swaybar to the vehicle.
5. Re check bolts after initial 100kms travelled.

Note: Longer swaybar links may be required on raised vehicles to maintain proper swaybar operation in all conditions - refer catalogue for application listings.



N.B: It is recommended that a licenced workshop or trades person carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.