

Instructions

Rear Brake Hose - Relocation

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

- Raise vehicle evenly and safely support.

Never rely on a Jack only.

- Using a screw-driver, push the steel clip off the brake line - refer image.
- Now pull steel brake line 'down' approx 30mm
- Bolt up new bracket with supplied M8 hardware as per image below.

Application - Isuzu D-max
- Holden Colorado

Always refer complete catalogue listing

Contents - Steel bracket x1
- M8 bolt x2
- M8 nut x2
- M8 washer x2



Bolt up new bracket with 2x M8 nuts and bolts.

Remove steel clip from here.

Re-issue clip to new bracket here.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.