

Instructions

Rear Swaybar

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application: Mitsubishi Triton MQ

1. Raise vehicle evenly and safely support.
2. Grease the supplied D bushings with supplied grease.
3. Proceed to hang the swaybar from the Axle mounting points - see image 1 for components required.
4. Do not tighten nuts yet.
5. Unbolt the Leaf spring front Eye nut (do not discard nut).
6. Place supplied 3mm spacer over the Leaf Eye bolt. Proceed to bolt up the supplied Link Plate - note components required below.
7. Bolt up supplied swaybar link to Plate and swaybar.
8. Check swaybar is central - now tighten all nuts and bolts.
9. Road test and re-check all components.



Axle mounting components - U bolts
Axle brackets
Flat plates
D Saddle
Flange nuts

Place 3mm spacer over Leaf Eye bolt before adding plate

Re-use OE nut

Use supplied 9mm spacer, M8 bolt and washer



Re-use OE leaf nut

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.