

Fitting Instructions #TRC3318IS

VW AMAROK 2010+
CV SHAFT BOLT KIT

Contents:

- 6 x Small Bolts
- 1 x Large Bolt

Note: 1 x Kit services one CV Shaft. (i.e. 2 x Kits are required per vehicle.)

Preparation Instructions:

- Remove Front Drive Shafts
- Remove Shock Absorbers.

Installation:

- Replace bolts ensuring threaded cavities are sufficiently cleaned of debris.
- Bolts are strictly single use only and must be torqued as follows.
- Torques:
 - 6 x Small External Bolts: 50Nm + 90° Extra Rotation
 - 1 x Large Internal Bolt: 150Nm + 180° Extra Rotation
- Re-assemble shock absorber and front drive shaft assembly.



Figure 01 – SAMPLE PHOTO OF CONTENTS



Figure 02 – CENTRE BOLT



Figure 03 – CV SHAFT WITH SMALL BOLTS