

Fitting Instructions #4907IS

**Holden Colorado/7 2012-on; Isuzu D-MAX/MU-X
2012-on; Toyota Hilux 2005-on; Prado 1996-on;
Land Cruiser 2007-on**

Strut Mount Bush Kit

Struts must be assembled and fitted to the vehicle by qualified persons only, using the appropriate procedures and equipment.

NOTE:

- The following diagram is generic. Components may vary throughout kits.
- Discard any rubber bushes or washers supplied with strut.

