

Install Guide

Sway Bar Relocation Plates

2012-2020 D-Max + 2012-2018 Colorado



Note: These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

Kit Contents:

- 2x Bracket
- 4x M8x25mm Bolt
- 4x M8x20mm Bolt
- 4x Spring washer

1. Remove the factory bash plates to provide better access to sway bar mounts.
2. Unbolt the sway bar mounts from the chassis rails
3. Slide the mount down the sway bar to give access to the chassis rails mounting holes.
4. Install the relocation brackets using the provided 25mm long 6mm hex bolts. Tension to 25Nm
5. Install the Sway Bar mounting brackets onto the relocation brackets using the provided 20mm long 6mm hex bolts and spring washers. Tension to 25Nm
6. Repeat these steps for the other side of the vehicle using the remaining hardware.
7. Ensure the brackets have moved the sway bar towards the front of the vehicle, the final product should appear as shown.

