

Install Guide

High Lift Sway Bar Spacer

Toyota LandCruiser GDJ79

4 Door Auto

Z7148-S
Page 1 of 1



Note: These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

Important: This spacer can accommodate up to a maximum shock length of 590mm provided castor and axle centering has been adequately compensated.

Kit Contents:

- 2 x Spacer 66672
- 4 x M8x1.25x85 Bolt
- 4 x M8x15.8x1.2 Washer



1. Raise the car or if completing on ground, secure the wheels with chocks and apply the handbrake.
2. Remove the 4 sway bar bracket bolts. Support the sway bar when removing the final bolt.
3. Line up the spacer on one side and loosely secure the bracket using the supplied hardware.
4. Complete the same for the other side then tighten all 4 bolts to manufactures specification.
5. To check for adequate driveshaft clearance, raise the vehicle so the front wheels are off the ground and front axle is at full droop. Check vertical clearance between the driveshaft and cross member. There should be at least 10-15mm. Ensure the wiring loom has some slack remaining.
6. Installation complete.

