

Install Guide

High Lift Cross Member Spacer

Toyota LandCruiser GDJ79

4 Door Auto

Z7146-S
Page 1 of 1



Note: These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

Important: This spacer can accommodate up to a maximum front shock length of 590mm provided castor and axle centering has been adequately compensated.

Kit Contents:

- 2 x Spacer 66675
 - 4 x M10x1.25x65 Bolt
 - 4 x M10x30x3 Washer
1. Raise the car, or if completing on ground, secure the wheels with chocks and apply the handbrake.
 2. Loosen the two bolts connecting the bash plate to the front cross member
 3. Remove the 4 bolts connecting the front cross member to the chassis. Brace the cross member when removing the final bolt.
 4. Insert the spacers and loosely secure the cross member using the supplied hardware.
 5. With all 4 bolts hand-tight, first tighten the right-hand side bolts to the manufacture's specification. Then tighten the left-hand side. Finally, re-tighten the two bash plate bolts to the manufacturer's specification.
 6. Check for adequate driveshaft clearance, raise the vehicle so the front wheels are off the ground and front axle is at full droop. Check vertical clearance between the driveshaft and cross member.
 7. Installation complete.

