

Install Guide

High Lift Rear Bump Stop Spacer

Toyota LandCruiser GDJ79

4 Door Auto

Z7149-S
Page 1 of 1



Note: These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

Kit Contents:

- 2 x Spacer 66674
- 4 x M8x1.25x75 Bolt
- 4 x M8x15.8x1.2 Washer



1. Raise the car or if completing on ground, secure the wheels with chocks and apply the handbrake.
2. Remove the 2 bolts securing the bump stop to the chassis.



3. Insert the spacer and secure the bump stop to the chassis using the supplied hardware. Tighten the bolts to the manufacturers recommended specification.
4. Complete for both sides.
5. If possible, safely flex the rear axle to bump stop and check:
 - a. The diff contacts at least 50% of the bump stops lower face.
 - b. The bump stop is fully engaged before the shock bottoms out.
 - c. Tyres do not contact body at full bump.
6. Installation complete.

