

Fitting Instructions



SKU

PRODUCT

T4M553

TAG HEAVY DUTY TOWBAR to suit Mazda CX-7 (10/2009 - 01/2012)



Scan for latest
version of these
instructions

SPECIFICATIONS

- Towbar Class: Heavy Duty
- Towing Capacity: 1600kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure, then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. Remove mud flaps by removing 4x screws (3 x inside wheel arch and 1x underneath)
2. Remove 2x screws from underside of bumper where mud flaps were.
3. Remove 1x screw from top of bumper behind wheel arch trim each side.
4. Remove taillights (3x10mm nuts behind each one)
5. Remove 2x plastic clips from under taillights.
6. Remove 2x plastic clips from underneath vehicle.
7. Gently peel bumper away from wheel arch working your way back to where the taillight was.
8. Remove bumper.
9. Remove impact beam 4 x 17mm nuts each side.
10. Place chassis inserts inside chassis rails, and line up with holes.
11. From underneath offer tow bar to vehicle, loosely fit all bolts then tighten

Towbar Fitting Instructions



12. Drill 10mm hole using tow bar as guide up through chassis and through the chassis insert on the driver's side and fit M10 x 35mm bolt plus s/washer and nut then tighten.
13. Refit impact beam and tighten.

Torque table for bolt tightening

Metric GRADE 8.8
M6 – 9.5 Nm
M8 – 21.7 Nm
M10 – 43.4 Nm
M12 – 77.3 Nm
M16 – 189.8 Nm

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au