## Z5386

FIG 3


## INSTRUCTIONS Rear Differential Rear Mount

## Suits: Toyota Rav4 4/1994 - 5/2000

N.B: This installation guide should be used in conjunction with the workshop manual.

FIG 1

FIG 2




1. Raise vehicle and safely support.

2. Remove the rear differential mount from the vehicle and place into a vice. Remove the rear plate using an angle grinder as in fig. 1&2

3. Using a hacksaw, cut through the OE bushing shell and remove the OE bushing from the housing as per fig. 3.

FIG 4

FIG 5



4. Clean the ID of the housing making sure it is free from any rust or burrs and insert the new bushing into the housing as per fig. 4.

5. Refit housing/bushing assembly to the differential, once fitted bolt the housing back up to the chassis as per fig. 5.

6. Tighten all bolts - re check after initial 100km.

<u>Warning:</u> Please drive carefully while you accustom yourself to the changed vehicle behaviour.