


Fitting Instructions #4754IS

Suzuki Swift

Engine Mount Front Bushing



- Remove the engine mount bracket;
- Remove original shell part from the bracket's housing with the use of a hydraulic press and suitable pressing tools;
- Clean any material left in the housing;
- Using the grease supplied, lubricate the housing and outer diameter of the new bush and push it into the bracket;
- Refit the engine mount bracket to the vehicle, and tighten all bolts to manufacture's torque settings.



Fitting Instructions #4754IS

Suzuki Swift

Engine Mount Front Bushing



- Remove the engine mount bracket;
- Remove original shell part from the bracket's housing with the use of a hydraulic press and suitable pressing tools;
- Clean any material left in the housing;
- Using the grease supplied, lubricate the housing and outer diameter of the new bush and push it into the bracket;
- Refit the engine mount bracket to the vehicle, and tighten all bolts to manufacture's torque settings.

