


Fitting Instructions #4649IS

Suzuki Swift

Engine Mount Front Bushing



Side View



- Remove the engine mount bracket from the car;
- Remove original shell part from the bracket's housing with the use of a hydraulic press and suitable pressing tools;
- Using the grease supplied, lubricate the housing and outer diameter of the new bush and push it into the bracket;
- Apply grease to the outside of the crush tube and press in the installed bush;
- Refit the engine mount bracket to the vehicle and tighten all bolts to manufacture's torque settings.


Fitting Instructions #4649IS

Suzuki Swift

Engine Mount Front Bushing



Side View



- Remove the engine mount bracket from the car;
- Remove original shell part from the bracket's housing with the use of a hydraulic press and suitable pressing tools;
- Using the grease supplied, lubricate the housing and outer diameter of the new bush and push it into the bracket;
- Apply grease to the outside of the crush tube and press in the installed bush;
- Refit the engine mount bracket to the vehicle and tighten all bolts to manufacture's torque settings.