

Fitting Instructions #1058IS

Subaru Various Models

Front Lower Control Arm

- Wheel align the vehicle before the job is started and note castor settings.
- Remove the control arms from the vehicle.
- Note some models with the protruding mounting peg will require the use of supplied washer.
- Position this washer onto mounting peg before offering up the control arms as per diagram below.
- Refit the control arms into the vehicle ensuring triangular mounting is reinstalled.
- Wheel align vehicle and check new settings.
- All mounting bolts are to be tightened to manufactures specifications with the vehicle at ride height.

