

# Fitting Instructions #4855IS

Toyota Hilux 8<sup>th</sup> Gen 2015-on

**Brake Hose and ABS Cable Mount Spacer Kit**

**Superpro**  
Suspension Parts

**Revision: B**

**Date: 16/12/2016**


*This kit must be fitted by qualified persons only, in conjunction with the factory service manual.*

*This kit **MUST** be fitted if extended length rear shock absorbers are installed.*

## Installation Instructions:

There are three locations where the spacer tubes must be fitted.

- **Location A:** The upper brake line bracket mount on the LHS of the vehicle in front of the rear shock absorber near the top. Approximate position is shown in *Picture 1* (obscured in this view by the spare wheel).
- **Location B:** The lower brake line bracket mount attached to the top of the differential housing on the LHS of the vehicle. Circled in *Picture 1*.
- **Location C:** The lower ABS cable bracket mount attached on top of the differential centre. Circled in *Picture 1*.




*Picture 1: Underneath view of Hilux rear axle*


Note: Production tubes have a smaller outside diameter to the tubes in the following pictures.

# Fitting Instructions #4855IS

**Location A:** Fit 2 x 20 mm long spacer tubes to the rear upper brake hose mount using 2 x 40 mm bolts with 1 x spring washer and 1 x flat washer per bolt. See *Picture 2* below for spacer positioning and *Picture 3* below for bolt/washer assembly order.



*Picture 2: Rear upper brake hose mount spacer position*




*Picture 3: Assembly of brake hose mount spacer*

**Location B:** Fit 1 x 10 mm spacer tube using 1 x 25 mm bolt with 1 x spring washer and 1 x flat washer to the rear lower brake hose mount. See *Picture 4* below for positioning and *Picture 5* below for bolt/washer assembly order.



*Picture 4: Rear lower brake hose mount spacer position*




*Picture 5: Assembly of brake hose mount spacer*

**Location C:** Fit 1 x 20 mm long spacer tube to the ABS cable mount using 1 x 35 mm bolt with 1 x spring washer and 1 x flat washer. See *Picture 6* below for positioning and *Picture 7* below for bolt/washer assembly order.



*Picture 6: ABS cable mount position*



*Picture 7: Assembly of ABS cable mount spacer*