

INSTALLATION INSTRUCTIONS



02115RW-TO SUIT SUZUKI GRAND VITARA 3 DOOR 9-2005-ON PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING:


1. Do not, drill, cut, weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.

Max. Towing Weight (Braked): 1600kg
Max Towing Weight (Unbraked): 550kg
Max Tow ball Download: 130 kg

- 1 Ensure all hardware items have been included
- 2 Remove rear muffler from its two rubber hangers.
- 3 Remove tow hook from driver side sub frame then discard.
- 4 Lift towbar into position then align slots in side plates with captive nuts in the sub frame then fasten with hardware supplied as per diagram on the next page.
- 5 Tighten all bolts to torque listing below.
- 6 Towbar rating sticker to be conspicuously located on inside rear end of the driver's door. (See diagram below)

NOTE: Hayman Reese recommends that you check your towball to ensure it complies with the Australian standard AS 4177.2.

PLEASE NOTE: It is advised to remove lug from receiver box when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide increased departure angle.



RECOMMENDED ASSEMBLY TORQUE LISTING


<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8

FOR TOWING PURPOSES ONLY
For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.

INSTALLATION INSTRUCTIONS



02115RW-TO SUIT SUZUKI GRAND VITARA 3 DOOR 9-2005-ON
PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN



HAYMAN REESE
PART No: 100712-WL
SUZUKI GRAND VITARA MY12

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

Wiring Loom Installation Instructions
SUZUKI GRAND VITARA MY12
Part No: 100712-WL
Tail Harness Length Required: 1200mm

Wiring Loom Installation Time: Approx. 45 minutes

Issue Date 31-03-14

Page 1

Part No: 100712-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100712-WL
SUZUKI GRAND VITARA MY12


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


1. Inside the luggage compartment, remove the parcel shelf (1) and the floor carpet cover (2).



2. Remove the rear luggage compartment trim (1) by pulling in an upwards direction.



3. Remove the LHS luggage compartment seat belt fastener (1) and luggage trim clip (2).
4. Remove the tool access panel (3) and jack (4).
5. Carefully peel open the LHS luggage trim and disconnect the 12 volt connector (5).



Issue Date 31-03-14

Page 2

Part No: 100711-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100712-WL
SUZUKI GRAND VITARA MY12


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


6. On the RHS luggage compartment trim, remove the seatbelt fastener and the trim clip (2).



7. On the rear RHS quarter of the luggage compartment area, drill a Ø30mm hole into the sheet metal in the area as shown (1). File hole and spray on rust inhibitor after drilling.



8. On the LHS of the luggage compartment, disconnect the tail light connector (2) and connect the trailer patch (100712-WL) connectors (3) in between.
9. Route the trailer harness (1) along the rear of the luggage compartment towards the RHS of the vehicle.



Issue Date 31-03-14

Page 3

Part No: 100711-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100712-WL
SUZUKI GRAND VITARA MY12

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


10. On the RHS of the luggage compartment, disconnect the tail light connector (1) and connect the trailer patch connectors (2) in between.



11. Mount the trailer socket (1) to the tow bar mounting bracket using M4 fasteners (not supplied).
12. Route the tail harness (2) across the tow bar towards the RHS of the vehicle and up through the previously drilled out hole.
13. Ensure the tail harness grommet is seated correctly and secure in place using a cable tie (not supplied).



14. Connect the tail harness (tail length 1200mm) 8-way connector (1) to the trailer patch mating 8-way connector (2).



Issue Date 31-03-14

Page 4

Part No: 100711-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100712-WL
SUZUKI GRAND VITARA MY12

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

- | | |
|---|--|
| <ol style="list-style-type: none">15. Test the trailer patch function using a light board or multi meter.16. Secure all harnesses using cable ties (not supplied).17. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.18. Place the fitting instructions in the glove box after fitment. | |
|---|--|

Issue Date 31-03-14

Page 5

Part No: 100711-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au

