

HAYMAN REESE
PART No: 02734W
Mazda 2 sedan 2010-On

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT



Installation Time: Approx **50** Mins

Towbar Installation Instructions
Mazda 2 Sedan

Towbar capacity

Part Number 02734W

Max Towing Braked 700kg
Max Static Ball Load 70kg

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE

PART No: 02734W

Mazda 2 sedan 2010-On

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS UNDERSTOOD PRIOR TO FITMENT

Warning:

1. Do not, drill, cut, weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.
1. **General:** Ensure all hardware items have been included refer to assembly diagram.
2. It is recommended that the instructions are read through and completely understood before making any attempt to fit this product.
3. Be wary of any changes to vehicle designs or other accessories that may conflict with the installation of this product.
4. Before drilling ensure that the area is clear of fuel, electrical & other components.
5. All holes drilled into the body panels shall have all burrs & swarf removed then coated with a suitable rust preventative paint.
6. The high tensile fasteners supplied with this product were used to achieve the specified rating. If replacement is required ensure that fasteners of the same rating & quality are used. Contact an authorised **Hayman Reese** dealer if further information is required.
7. Ensure that all hardware is fastened to torque list below check fasteners on regular basis.
8. Towbar load rating sticker provided with this product shall be conspicuously located on inside rear end of the driver's door. **(See diagram below).**
9. Hayman Reese recommends that you check your tow ball to ensure that it complies with the Australian standards **AS 4177.2**.
10. **PLEASE NOTE:** It is advised to remove your lug or tbm when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide maximum available departure angle.


Tow bar Maintenance and Care.

Hayman Reese recommends that bolt torque's, as listed below, are routinely and regularly inspected and checked for correct tension. Replace any worn or defective parts.

We recommended to remove Tow Ball Mounts (TBM's, tongues or lugs) when not being used for any considerable length of time.

So as to avoid injury, when not towing it is suggested that the tongue, Pull Pin and R-clip are removed then stored in a safe, clean and dry place, away from excessive moisture.

Hitch Pull Pins and spring "R" clips are regularly checked for proper installation. Replace any worn or defective parts.



Place load rating sticker
inside driver's door here

RECOMMENDED ASSEMBLY TORQUE LISTING

Diameter Grade 8.8 Bolt

M6	9.5 Nm
M8	21.7 Nm
M10	43.4 Nm
M12	77.3 Nm
M14	146 Nm
M16	189.8 Nm

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.

Issue Date 8/10/10

Page 2

Part No: 02734W


HAYMAN REESE

PART No: 02734W

Mazda 2 sedan 2010-On


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS UNDERSTOOD PRIOR TO FITMENT




QTY.	DESCRIPTION	ITEM NO.
1	MAZDA 2 WELD ASSY.	1
1	LUG	2
4	WSHR FT M10 X 25.4 X 3	3
4	M10 X 3.5 X 2.2 SPRING WSHR	4
4	M10 - 1.5 x 35mm BOLT	5
2	M16 X 5 X 3.5 SPRING WASHER	6
2	M16 x 45 2.0P BOLT	7

ADDITIONAL ITEMS



D SCHAKLES



WIRING LOOM



FITTING INSTRUCTIONS



LOAD RATING LABEL



WARRANTY CARD





HAYMAN REESE

PART No: 02734W

Mazda 2 sedan 2010-On

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS UNDERSTOOD PRIOR TO FITMENT

	<ol style="list-style-type: none">1. Remove 4 screws and 1 skivet around wheel arch area on both sides.2. Remove 2 skrivets under the bumper.3. Open the booth lid and remove 2 screws between the cavities.
	<ol style="list-style-type: none">4. Loosen taillight assemblies via accessing from inside the booth.5. Remove bumper and disconnect any wirings connecting to the bumper.
	<ol style="list-style-type: none">6. Using appropriate tool, cut open rear panel to access to chassis rails.7. Insert towbar into chassis rails, fit tow bar to chassis rails using M10 bolts, flat washers and spring washers supplied.8. Torque all fastens to specifications on page 2.
	<ol style="list-style-type: none">9. Using number plate lights as a guide, cut 120mm wide by 55mm deep from the bottom of the bumper.10. Refit bumper bar to vehicle.

HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

Wiring Loom Installation Instructions

MAZDA 2 SEDAN
Part No: 100505-WL

Tail Harness Length Required: 1200mm
RPA Override Switch Part No: 04848 (If Fitted)

Wiring Loom Installation Time: Approx 30 Mins

Issue Date 20-10-10

Page 1

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


1. In the luggage compartment, remove the floor cover carpet (1).



2. Remove the rear trim (1) by first removing the two clips (2).



3. Remove the LHS side trim (1) by first removing the five clips (2).



Issue Date 20-10-10

Page 2

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

4. Remove the RHS tail light access panel cover (1).



5. Remove the LHS grommet (1).
6. Drill out the grommet hole to Ø31mm.
7. File any rough or sharp edges and spray on rust inhibitor.



8. Remove the luggage compartment foam tool tray (1).



Issue Date 20-10-10

Page 3

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

9. Route the trailer patch harness (P/No:100505-WL) (1) under the RHS side trim and up towards the RHS tail light assembly.

10. Disconnect the RHS tail light indicator 3-way connector (2).

11. Patch in the trailer patch mating connector (3).

12. Route the trailer patch harness from the RHS tail light assembly and towards the rear of the luggage compartment.




13. Route the trailer patch harness (1) along the rear of the luggage compartment towards the LHS.



14. Route the trailer patch harness (1) towards the LHS tail light assembly.

15. Disconnect the LHS tail light connectors (2).

16. Patch in the trailer patch mating connectors (3).



Issue Date 20-10-10

Page 4

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

17. In the upper LHS of the luggage compartment, locate the white connector (1).
18. Following the table below, connect the ezy tap (2) to the vehicle 'RED/YELLOW' reverse wire (3) then connect the trailer harness 'BLACK' reverse wire terminal (4) to the ezy tap (2).

Function	Trailer Patch	Vehicle Connector
REVERSE	BLACK	RED / YELLOW



19. Connect the trailer patch harness ground ring terminal (1) to the LHS tail light assembly bolt (2).



20. Mount the trailer socket to the towbar mounting bracket using M4 fasteners (not supplied).
21. Route the tail harness across the towbar towards the RHS of the vehicle and up through the previously drilled out hole.
22. Ensure the tail harness grommet is seated correctly and secure in place using a cable tie (not supplied).



Issue Date 20-10-10

Page 5

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au




HAYMAN REESE
PART No: 100505-WL
MAZDA 2 SEDAN

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

23. Connect the tail harness (tail length 1200mm) 8-way connector (1) to the trailer harness mating 8-way connector (2).



24. Test the trailer harness function using a light board or multimeter.
25. Secure all harnesses using cables ties (not supplied).
26. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.
27. Place instructions in glove box after fitment

Issue Date 20-10-10

Page 6

Part No: 100505-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au

