

## **TN-TP MAGNA & SONATA CASTER KITS**

**Please Note:** URETHANE BUSHES MUST BE FITTED TO BOTH SIDES

### **STANDARD REPLACEMENT/ALIGNMENT**

**Kit contents:** 2 x 9049 Left/Right Hand Side

Original equipment style bushes, which maintain existing caster settings.

### **0.8 DEGREE CASTER ADJUSTMENT LEFT SIDE**

**Kit contents:** 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)  
1 x 9049 Right Hand Side (Maintains existing caster settings)

### **0.8 DEGREE CASTER ADJUSTMENT BOTH SIDES**

**Kit contents:** 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)  
1 x 9051 Right Hand Side (Offset gives -0.8 Degree caster)

**NB:** Pivot shafts and mounting brackets must be free from dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with grease provided.

Fitting the correct bush to the car, the word “**FRONT**” moulded into the bush must be facing downwards and forwards (the word “**FRONT**” is clearly visible once fitted).

All mounting bolts are to be torque to MANUFACTURES SPECIFICATIONS with the vehicle at normal ride height.

## **TN-TP MAGNA & SONATA CASTER KITS**

**Please Note:** URETHANE BUSHES MUST BE FITTED TO BOTH SIDES

### **STANDARD REPLACEMENT/ALIGNMENT**

**Kit contents:** 2 x 9049 Left/Right Hand Side

Original equipment style bushes, which maintain existing caster settings.

### **0.8 DEGREE CASTER ADJUSTMENT LEFT SIDE**

**Kit contents:** 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)  
1 x 9049 Right Hand Side (Maintains existing caster settings)

### **0.8 DEGREE CASTER ADJUSTMENT BOTH SIDES**

**Kit contents:** 1 x 9051 Left Hand Side (Offset gives +0.8 Degree caster)  
1 x 9051 Right Hand Side (Offset gives -0.8 Degree caster)

**NB:** Pivot shafts and mounting brackets must be free from dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with grease provided.

Fitting the correct bush to the car, the word “**FRONT**” moulded into the bush must be facing downwards and forwards (the word “**FRONT**” is clearly visible once fitted).

All mounting bolts are to be torque to MANUFACTURES SPECIFICATIONS with the vehicle at normal ride height.