










# RIDGE MOUNT

by **ROLA**<sup>®</sup>



Read this full instruction prior to commencing assembly and fitment of Ridge Mount System.

## CONTENT - CHECK ALL PARTS ARE CORRECT BEFORE PROCEEDING


A		Ridge Mount (pair)	1
B		Stud Plate	4
C		M8x25mm Socket Head Screw	16
D		M8 Washer	32
E		M8 Nyloc Nut	16
F		M8 Flanged Nut	8
G		Butyl Patch	16
H		Interlocking Block	3

## TOOLS REQUIRED

- 6mm allen tool.
- Socket wrench and set.
- Step ladder.
- Trim tools.
- 10mm spanner.
- Phillips head screwdriver.
- T27 socket/ screwdriver

1


Gain access to the front passenger side of the vehicle.



2


Carefully release the first part of the sun visor bracket from the vehicle by twisting it anti-clockwise and pulling down.

Release the remaining bracket by bringing the two locking tabs together and pulling down.




3

Lower the sun visor downwards to gain access to the sun visor mounting bracket cover, release the sun visor bracket cover from the bracket. Release the hardware holding the sun visor to the vehicle by releasing the 2 Phillip Head Screws.




Disconnect the sunvisor wiring harness connector from the vehicle.




4

Gain access to the overhead console of the vehicle and release by prying using a trim removal tool.




5

Disconnect the wiring harness connectors from the overhead console.



6


From the front drivers side of the vehicle, release the door seal from the upper door frame. Continue to release the door seals from the other three door frames and finish at the front passenger side.



7

From the front passenger side, remove the A-pillar trim from the vehicle by releasing the handle.


Release the two covers on the handle and then release the hardware using an 8mm socket.



8


Release the A-pillar trim from the vehicle by releasing the clips on the upper A-pillar trim.

Lift the A-pillar trim upwards to release the A-pillar trim from the vehicle and remove.




9

Gain access to the upper B-pillar trim by releasing the fixing cover and fastener, holding the upper B-pillar trim in place.




10

Remove the B-pillar handle by releasing the cover and fasteners holding the handle in place.



11



Release the lower B-pillar trim from the vehicle by releasing the upper clips of the lower B-pillar trim that hold the trim into place. This allows enough access to the upper B-pillar trim clips that are sitting behind the lower B-pillar trim.



12


A - Release the upper B-pillar trim lower clips that sit behind the lower B-pillar trim.

B - Release and set aside the upper B-pillar trim from the vehicle.




13

Release the rear ceiling light from the vehicle, disconnect the wiring harness from the ceiling light.





14

Fold down the rear seats of the vehicle to gain access to the rear wall trim to remove the C-pillar trims.



15


Release the rear middle seatbelt cover from the rear wall trim plate assembly.



16


Remove the rear wall trim plate assembly from the vehicle by releasing the clips holding the trim into place on the vehicle.

Slide the rear wall trim plate assembly along the seat belts, allowing access to the C-pillar trims.




17

Gain access to the upper C-pillar trim by releasing the fixing cover and fastener holding the upper C-pillar trim into place.



18

Release the lower C-pillar trim enough to allow access to the upper C-pillar trim by releasing the lower C-pillar trim towards the centre of the vehicle.






19

Release the upper C-pillar trim lower clips that sit behind the lower C-pillar trim.


Release the remaining clips on the upper C-pillar trim and set trim aside.



20



Release the headliner from the vehicle by releasing the velcro around the sunroof of the vehicle and then release the 2 clips at the rear of the cabin.

Lower the headliner to rest on the seats of the vehicle.




21

Gain access to the vehicle roof rails. Release the hardware holding the roof rails in place and release the roof rails from the vehicle.




22

Place 2x butyl patches over each cavity now exposed in the roof.



23

Install the M8 Washers and M8x25mm Socket Head Cap Screws into each of the Ridge Mounts.





24

Install the Ridge Mounts to each side of the vehicle.

From inside the cabin of the vehicle, install the M8 Serrated Flange Nuts to the M8 Socket Head Cap Screws.


Torque the M8 Serrated Flange Nuts to 25Nm.



25

Install the stud plates onto the Ridge Mounts.


Fasten these stud plates using the M8 Washers and M8 Nyloc Nuts.



26

Re-install the headliner of the vehicle by repeating steps 2-20 in reverse order.



Check all fasteners.




## TITAN TRAY FITMENT

27


Install the Rola Titan Tray as per corresponding instructions.



Note:



Wiring can be run and secured on the underside of the Ridge Mount rail as shown.



## IMPORTANT - READ BEFORE USE

Please ensure the system is fitted in accordance with the fitting instructions.  
It is important that you observe all outlined below.



## WARRANTY INFORMATION

Rola warrants that, subject to exclusions and limitations below, the system will be free from defects in materials and workmanship for a period of 2 years commencing on the date of sale by the authorized Rola stockist to the original purchaser of the system.

If a defect appears in the system before the end of the warranty period and Rola finds that the defect is in materials or workmanship, Rola will, in its sole discretion, either:

1. Repair the system or the defective component of the system free of charge
2. Replace the system or the defective component of the system; or
3. Refund the purchase price of the system to the original purchaser.

Rola reserves the right to change the design, specifications or composition of the system without notice and without liability. Rola reserves the right to replace defective products or components with products or components of similar quality, grade and composition, where an identical product or component is not available. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. The 2 year warranty does not apply where:

1. The system is not installed in compliance with the fitting instructions provided
2. The system is not used as intended or designed
3. The system has been on-sold or assigned by the original purchaser
5. The system has been modified or repaired by someone other than Rola or an authorized Rola stockist
6. Rola cannot establish any fault after inspection of returned product
7. The system has been subject to abnormal conditions, including fire, water, humidity, pressure, stress or similar
8. The defect in the system has arisen due to abuse, misuse, neglect or accident
9. The defect in the system has arisen due to the unlawful or unusual operation of the vehicle to which it is fitted
10. The defect in the system has arisen due to the purchaser's failure to properly assemble, install, fit, maintain or use the system in accordance with the specifications and instructions provided by Rola.


For safety and use instructions, please refer to any General or Specific Fitting Instructions and Warning & Care Instructions enclosed within the system or on our website at [www.rola.com.au](http://www.rola.com.au).

This warranty does not extend to fair wear and tear. Warranty claims can be made by contacting Rola directly using the details below. A warranty claim must be accompanied by proof of purchase (such as receipt), details of the alleged defect and appropriate documentation (such as historical and maintenance records where appropriate). The customer must make the product available to Rola or its authorized repair agent for inspection and testing. If such inspection and testing finds no defect in the product, the customer must pay Rola usual costs of service work and testing. It is the purchaser's responsibility to arrange and pay to return the product or component to the place of purchase. The purchaser may seek reimbursement from Rola for the cost of such activities, providing Rola notifies the purchaser in writing that a warranty claim is justified. Any such claims made must be in writing via post or email.


The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be executed. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be so excluded, restricted or modified. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Rola makes no express warranties or representations other than set out in this warranty.

## SAFETY REQUIREMENTS

Manufactures roof weight limit - rack system weight = Max carrying capacity.




Cross reference with system max carrying capacity. **Always use the lower of the two figures.**




### IMPORTANT - Off-road load rating reduction.

System	Track Mount	Anchor Point	Gutter Mount	Raised Rail	Flush Rail	Clamp Mount
Platform+ Ridge Mount	0%	0%	25%	0%	N/A	N/A
Platform+ Low Mount	33%	33%	33%	33%	33%	50%
Sports Extended	33%	33%	33%	33%	33%	50%
Sports Concealed	33%	33%	33%	33%	33%	50%




Distribute carried load evenly longitudinally and as low as possible.


CORRECT




CORRECT






Do not concentrate loads front or rear.




CORRECT



CORRECT




CORRECT





600mm+ overhang must be tied to front of vehicle.




## SAFETY REQUIREMENTS




Check all fixtures are secured and torqued correctly.




Check all fixtures are secured and torqued correctly.



Do not use car-wash with roof rack systems.



Be aware of adjusted vehicle height.



Cab and canopy can move independently, do not fix load across both.

Long loads fixed at front only.

