

# Install Guide

## Handbrake Cable Relocation Kit

### Toyota LandCruiser 70 Series



**Note:** These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.


#### Kit Contents:

- 1x Bracket
- 1x 15x11mm Sleeve
- 1x 22x20mm Spacer
- 3x M8x35mm Bolt
- 2x M8 Nut
- 5x M8 Washer
- 1x M10 Washer
- 1x M8 Spring Washer

1. Chock the wheels in both directions and release the handbrake.
2. Start by removing the bracket on the rear differential housing shown below in the left image. Space the bracket by placing the spacer between the bracket and the diff securing it with an M8 washer, M8 spring washer and M8 bolt as shown in the right image. Ensure the bracket orientation is correct to minimize the cable rubbing on the nylon bush.



3. Remove the bracket attached to the left side of the diff housing by removing the large bolt. Once removed, free the handbrake cable by removing the center bolt.




# Install Guide

## Handbrake Cable Relocation Kit


### Toyota LandCruiser 70 Series



4. Reusing the items shown in the left image, loosely assemble the new bracket as shown in the middle and right images.



5. Re-insert the handbrake cable into the brackets provisions and tighten the two M8 bolts. Ensure the sleeve fits into the original bracket for a flush finish. Then secure the large bolt into its original position as shown. This bolt is designed to pivot.



6. Torque all bolts to manufacturer's specs.
7. Ensure handbrake continues to function as intended.
8. Recheck all bolts after 1,000 km or 1 month.
9. Installation is complete.