

# Fitting Instructions #4839IS



Renault Trafic / Opel Vivaro / Vauxhall Vivaro / Nissan Primastar

Front Control Arm Lower Rear Bushing




Figure 01 – Left Hand Side Control Arm

Figure 02 – SuperPro kit installation

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands / hoist, and remove the lower control arms;
- Remove original shell part from the rear housing of the arm with the use of a hydraulic press and suitable pressing tools;
- Install the new SuperPro bushes into the rear bush housing of the control arm;
- Apply the supplied grease to the bore of the bush, the outside of the crush tube and the inside of the polyurethane spacers;
- Push in the crush tube and fit the polyurethane spacers;
- Refit the control arm to the vehicle and tighten all bolts to manufacture's torque settings;
- Carry out a wheel alignment.

**Note:** Polyurethane bushings must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.

# Fitting Instructions #4839IS



Renault Trafic / Opel Vivaro / Vauxhall Vivaro / Nissan Primastar

Front Control Arm Lower Rear Bushing




Figure 01 – Left Hand Side Control Arm

Figure 02 – SuperPro kit installation

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands / hoist, and remove the lower control arms;
- Remove original shell part from the rear housing of the arm with the use of a hydraulic press and suitable pressing tools;
- Install the new SuperPro bushes into the rear bush housing of the control arm;
- Apply the supplied grease to the bore of the bush, the outside of the crush tube and the inside of the polyurethane spacers;
- Push in the crush tube and fit the polyurethane spacers;
- Refit the control arm to the vehicle and tighten all bolts to manufacture's torque settings;
- Carry out a wheel alignment.

**Note:** Polyurethane bushings must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.