

Fitting Instructions #4849IS

Chevrolet Corvette

Rear Strut Rod Bush Kit



- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist and remove the strut rods;
- Remove original shell part from the inner and outer housing of the strut rod with the use of a hydraulic press and suitable pressing tools;
- Apply the supplied grease to the outside surfaces of the bush and inside the housing;
- Push the new '4849' bushes into the inner and outer strut rod housings according to the Figure 01 and Figure 02. Note that the side of the bush to be pushed into the arm housing first has a bigger chamfer and is marked with the letter "A";
- Apply the supplied grease to the bore of the bush and outside of the crush tube, and then press the tube in, Figure 01 ;
- Apply the same procedure to the other strut rod of the vehicle;
- Refit the strut rods to the vehicle and tighten all bolts to manufacture's torque settings and carry out a wheel alignment.




Figure 01 – Strut Rod Bush




Figure 02 – Strut Rod

Note: Polyurethane bushings must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.